

Item	Part Number	Description	Qty
1	GB5781-B6-22	Bolt M6×22	1
2	GB90-W-6	Washer ø6	6
3	GB93-LW-6	Lock Washer ø6	6
4	GB41-N-6	Nut M6	2
5	ST05FD-1151202-10A	10 Amp Circuit Breaker	1
6	ST02FD - 1150123M	L5-20R AC Receptacle	1
7	DP03-00000000-1	Intelligauge II	1
8	ST168F-1121100-C	Switch	1
9	ST01FD-05010600	Control Panel	1
10	GB5789-FB6-12	Flange Bolt M6×12	16
11	GB1667-S4-12	Screw M4×12	5
12	GB93-LW-4	Lock Washer ø4	2
13	GB90-W-4	Washer ø4	2
14	ST154FD-3000004	Rear Frame	1
15	ST154FD-3000001	Alternator Rear Cover	1
16	ST154FD-4040000	Condenser	1
17	GB41-N-4	Nut M4	1
18	ST152FD-1171200	Control Panel Cover	1
19	GB1667-S5-12	Screw M5×12	2
20	ST154FD-11004000	Muffler support	1
21	ST154FD-3000008	Screw M6x90	4
22	GB16674-96-S5-12	Screw M5x12	2
23	ST02FD-1151201	Build up	1
24	ST02FD-05212007	Conduit	1
25	ST02FD-1151201	Build up	1
26	GB41-N-6	Nut M6	1
27	ST02FD-1151207-M	Grounding Wire	1
28	ST154FD-2000003	Motor Mount C, Rear	2
29	GB41-N-8	Nut M8	10
30	GB5789-FB8-12	Flange Bolt M8×12	2
31	ST02FD-1151400-19	Rubber Pad	4
32	ST154FD-2000002	Motor Mount A, Right	1
33	ST154FD-2000001	Motor Mount B, Left	1
34	ST152FD-2-1000000G	Engine	1
35	ST160F-1010002	Exhaust Bolt	2
36	ST154FD-1100100	Exhaust Gasket	1
37	ST154FD-1110000	Muffler	1
38	GB93-LW-8	Lock Washer ø8	3
39	GB90-W-8	Washer ø8	3
40	GB41-N-8	Nut M8	2
41	ST168FD-1160400	Fuel Cock	1
42	ST154FD-1070300	Fuel Meter Assembly	1
43	ST154FD-1070200	Fuel Filter	1
44	ST168FD-1160200	Fuel Tank Cap	1
45	GB5789-FB6-20	Flange Bolt M6×20	4
46	ST02FD-04100014	Washer ø6.5	4
47	ST168FD-1163000	Tank Grommet	4
48	ST152FD-1070006	Clip	1
49	ST154FD-1070002	Fuel Hose	1
50	ST188FD-1070006A	Clip	1
51	ST154FD-1070100	Fuel Tank	1
52	ST154FD-2001000-D	Frame	1
53	ST154FD-2001002-D	Fuel Tank Wing	2
54	ST154FD-3000005	Alternator Front Frame	1
55	GB5789-FB8-20	Flange Bolt M8×20	4
56	ST154FD-3001000	Rotor Comp	1
57	ST154FD-3000006	Stator Cover	1
58	ST154FD-3002000	Stator Assembly	1
59	ST154FD-3000007	Alternator Center Screw M8×170	1
60	GB819-85-S5-10	Screw M5×10	2