

Item	Part Number	Description	Qty
1	GB1667-S5-10	Screw M5×10	2
2	ST168FD-1160100	Fuel Meter Assembly	1
3	ST168FD-1160200	Fuel Tank Cap	1
4	ST168FD-1160201	Fuel Tank Cap Seal	1
5	ST168F-1160500	Fuel Filter	1
6	GB5789-FB6-20	Flange Bolt M6×20	4
7	ST02FD-04100014	Washer ø6.5	4
8	ST168FD-1163000	Tank Grommet	4
9	ST168FD-1160001A	Fuel Tank	1
10	ST168FD-1160400	Fuel Cock	1
11	ST168FD-1160002A	Fuel Line	1
12	ST188FD-1070006A	Clip	2
13	GB5789-FB6-12	Flange Bolt M6×12	7
14	GB5789-FB8-20	Flange Bolt M8×20	3
15	ST02FD-1150100	Muffler Stay, II	1
16	ST168FD-1100002B	Muffler Stay	1
17	ST168FD-1150230	Terminal	1
18	GB5789-FB5-12	Flange Bolt M5×12	2
19	ST02FD-1152002	Generator End Cover	1
20	GB5789-FB5-16	Flange Bolt M5×16	2
21	ST168FD-1152031	AVR	1
22	GB5781-B5-16	Bolt M5×16	4
23	GB93-LW-5	Lock Washer ø5	3
24	GB90-W-5	Washer ø5	3
25	ST02FD-1152035	Brush Assembly	1
26	GB5789-FB6-158	Flange Bolt M6×158	4
27	GB93-LW-6	Lock Washer ø6	4
28	GB90-W-6	Washer ø6	4
29	ST02FD-1152032	End Cover	1
30	ST02FD-1152001-2.5	Stator Cover	1
31	ST02FD-1152020-2.5	Stator Assembly	1
32	GB5789-FB8-233	Flange Bolt M8×233	1
33	GB93-LW-8	Lock Washer ø8	3
34	GB90-W-8	Washer ø8	1
35	ST02FD-1152010-2.5	Rotor Comp	1
36	ST02FD-02100012	Grommet, I	1
37	ST02FD-02100011	Grommet, II	1
38	ST168FD-2-01000000G	Engine	1
39	ST02FD-1151207-M	Grounding Wire	1
40	GB41-N-6	Nut M6	1
41	ST02FD-1151300B	Motor Mount I	2
42	GB41-N-8	Nut M8	12
43	ST02FD-1151400-19	Rubber Pad	4
44	ST02FD-1151300A	Motor Mount II	2
45	ST02FD-03141000	Frame	1
46	ST02FD-1151002	Muffler Cover	1
47	ST168FD-1090006	Air Cleaner Stay	1
48	GB5789-FB6-8	Flange Bolt M6×8	1
49	ST160F-1100001-G	Muffler Gasket	1
50	GB90-W-8	Washer ø8	2
51	GB41-N-8	Nut M8	2
52	ST168FD-1100000-G	Muffler	1
53	ST188FD-1180121	Spark Arrester Assembly	1
54	ST188FD-1100010-88	Spark Arrester Cover	1
55	GB93-LW-5	Lock Washer ø5	2
56	GB5789-FB5-15	Flange Bolt M5×15	2
57	ST02FD-1152036	Brush Support Plate	1
58	ST05FD-1170003-B	Grommet	1
59	ST05FD-1151209	Conduit	1
60	ST02FD-1151201	Grommet	1

61	GB1667-S5-38	Screw M5×38	3
62	GB90-W-5	Washer ø5	3
63	OV01-00000000-1	Transition	1
64	GB6177-86-N4	Nut M4	5
65	GB818-85-S4-14	Screw M4×14	1
66	ST02FD-1151300	Control Box	1
67	GB5781-B6-22	Bolt M6×22	1
68	GB90-W-6	Washer ø6	2
69	GB93-LW-6	Lock Washer ø6	2
70	GB41-N-6	Nut M6	2
71	ST02FD-05010703	Bolt M5×12	4
72	ST02FD-1151203M	5-20R AC Receptacle	1
73	ST02FD-1151202M	RV Receptacle	1
74	GB1667-S4-10	Screw M4×10	6
75	ST02FD-05502020	Receptacle L5-30R	1
76	ST02FD-05602010-D	Volt Meter	1
77	ST02FD-05302001-L20	20 Amp Circuit Breaker	1
78	ST02FD-05302001-L25	25 Amp Circuit Breaker	1
79	ST02FD-05015600	Control Panel	1
80	ST02FD-1151205A	Engine Switch	1