

Item	Part Number	Description	Qty.
1	ST05FD-05705005	Switch	1
2	ST05FD-05017500	Control Panel	1
3	ST05FD-1151220-CSA	25A Double Throw Breaker	1
4	ST168FD-1716000-CSA-2	20A Double Throw Breaker	1
5	ST05FD-1151204-CSA	Volt Meter	1
6	ST188FD-1710001-CSA	Receptacle L5-30R	1
7	ST188FD-1710002-CSA	Receptacle L14-30R	1
8	ST188FD-1710003-CSA	Receptacle L5-20R	1
9	ST05FD-1151208-M	Grounding Bolt	1
10	ST188FD-1151201-CSA	Wiring Contol Box	1
11	ST05FD-1170003-B	Grommet	1
12	ST05FD-1151209-CSA	Conduit	1
13	ST05FD-1170003-B	Grommet	1
14	GB1667-S5-35	Screw M5×35	3
15	GB5789-FB5-10	Flange Bolt M5×10	2
16	ST05FD-1152002	Generator End Cover	1
17	GB5789-FB6-16	Flange Bolt M6×16	7
18	ST168F-1152032-CSA	Terminal	1
19	ST05F-1152012-CSA	AVR	1
20	ST02FD-1152036	Brush Support Plate	1
21	ST05FD-1152035	Brush Assembly	1
22	ST05FD-1152032	End Cover	1
23	GB5789-FB6-165	Flange Bolt M6×165	4
24	ST04FD-1152001	Stator Cover	1
25	GB5789-FB10-1.25-250	Flange Bolt M10×1.25×250	1
26	ST04FD-1152020-CSA	Stator Assembly	1
27	GB93-LW-10	Lock Washer ø10	1
28	GB90-W-10	Washer ø10	1
29	ST04FD-1152010-CSA	Rotor Comp	1
30	GB5789-FB6-10	Flange Bolt M6×10	3
31	ST05FD-1151600	Filter Cover	1
32	ST188FD-1030011-B	Crankcase Cover	1
33	ST1P60F-1030004	O-Ring	1
34	ST188F-1030003	Oil Filler Cap	1
35	ST182FD-1000000	Engine	1
36	ST05FD-1151206	Fuel Cut Off Solenoid	1
37	ST182FD-1151110-B	Handle	1
38	ST05FD-03501000	Frame	1
39	ST02FD-1151207-M	Grounding Wire	1
40	ST05FD-1151300A	Bottom Rubber 1	2
41	ST05FD-1151300B	Bottom Rubber 2	2
42	GB41-N-8	Nut M8	4
43	GB41-N-10	Nut M10	2
44	GB41-N-10	Nut M10	4
45	GB5789-FB6-12	Flange Bolt M6×12	2
46	ST182FD-1742002-CPE	Control Panel Protector	1
47	ST160F-1070001	Clip	6
48	ST188FD-1160002-CPE	Fuel Tube	1
49	ST168FD-1160400	Fuel Cock	1
50	ST188FD-1160001	Fuel Tank	1
51	ST168F-1160500	Fuel Filter	1
52	ST168FD-1160200	Fuel Tank Cap	1
53	GB1667-S5-6	Screw M5×6	2
54	ST168FD-1160100	Fuel Meter Assembly	1
55	GB5789-FB6-25	Flange Bolt M6×25	4
56	GB90-W-6	Washer ø6	4
57	ST168FD-1163000	Tank Rubber	4
58	ST182FD-1130001	Packing (II)	1
59	ST182FD-1130100-C	Choke Lever Comp	1
60	ST182FD-1133000-A	Carburetor	1

61	ST182FD-1130002	Packing (I)	1
62	ST182FD-1134000	Carburetor Insulator	1
63	ST182FD-1130003	Carburetor Insulator Packing	1
64	ST188FD-1010002	Intake Stud	2
65	GB90-W-8	Washer ø8	2
66	GB93-1987-SW8	Lock Washer ø8	2
67	GB41-2000-N8	Nut M8	2
68	GB6177-86-N6	Nut M6	4
69	ST188FD-1090006	Air Cleaner Stay	1
70	ST188FD-1090100	Air Cleaner Case Comp	1
71	ST188FD-1090002	Air Cleaner Seal	1
72	GB41-N-5	Nut M5	6
73	ST188FD-1090003	Separator	1
74	ST188FD-1090004	Element	1
75	ST188FD-1090200	Air Cleaner Cover Comp	1
76	ST188FD-1080200	Control Assembly	1
77	ST188FD-1010001	Exhaust Stud	2
78	ST188FD-1100001	Exhaust Gasket	2
79	ST05FD-1100100	Exhaust Pipe	1
80	GB5781-B8-25	Bolt M8×25	2
81	ST188FD-1100002-CPE	Muffler	1
82	ST188FD-1100105	Muffler Outer Protector	1
83	GB5789-FB6-12	Flange Bolt M6×12	10
84	ST188FD-1100104	Muffler Life Protector	1
85	ST188FD-1180121	Spark Arrester Assembly	1
86	ST188FD-1100010-88	Spark Arrester Comp	1
87	GB5789-FB5-14	Flange Bolt M5×14	2
88	GB93-LW-5	Lock Washer ø5	2
89	ST188FD-1100103	Muffler Inner Protector	1
90	GB5789-FB8-20	Flange Bolt M8×20	5
91	ST188FD-1100006	Muffler Stay	1
92	GB5789-FB8-30	Flange Bolt M8×30	2
93	ST188FD-1740004-C	Vibration Mount	2
94	ST177FD-1743001-C	Support Leg	1
95	GB5781-B8-12	Bolt M8×12	5
96	ST177FD-1152300	8" Wheel	2
97	ST02FD-03621001	Bushing ø10.5×58.5	2
98	GB90-W-10	Flat Washer ø10	2
99	GB5781-B10-105	Bolt M10×105	2
100	GB41-N-8	Nut M8	2
101	GB5789-FB8-45	Flange Bolt M8×45	2